

---

**NEW ZEALAND and AUSTRALIAN PRS (UHF CB) RADIO CHANNELS**

---

40 channels are allocated to the PRS Radio Service in New Zealand and Australia. The frequencies range from 476.4250MHz to 477.4000MHz in 25kHz steps.

Channels 1-8 are Repeater pairs with channels 31-38 (750kHz offset)

Channels 1-8 are the Repeater Outputs whilst Channels 31-38 are the Inputs

All 40 channels can be used in Simplex mode, but users must be aware of the Repeater pairing listed above

Only allowable Mode: NFM. CTCSS tones are allowed  
Maximum Power: 5W

Ch	Frequency (MHz)	Ch	Frequency (MHz)
1	476.4250 (31)	21	476.9250
2	476.4500 (32)	22	476.9500
3	476.4750 (33)	23	476.9750
4	476.5000 (34)	24	477.0000
5	476.5250 (35)	25	477.0250
6	476.5500 (36)	26	477.0500
7	476.5750 (37)	27	477.0750
8	476.6000 (38)	28	477.1000
9	476.6250	29	477.1250
10	476.6500	30	477.1500
11	476.6750	31	477.1750 (1)
12	476.7000	32	477.2000 (2)
13	476.7250	33	477.2250 (3)
14	476.7500	34	477.2500 (4)
15	476.7750	35	477.2750 (5)
16	476.8000	36	477.3000 (6)
17	476.8250	37	477.3250 (7)
18	476.8500	38	477.3500 (8)
19	476.8750	39	477.3750
20	476.9000	40	477.4000